

King Size Bed with Center Leg Assembly Instructions

This page of instructions is for a King Size or larger custom bed built with a center leg. To make sure the center leg is placed in the exact center we will provide you with two spacer bars. The bars will be labeled "Center Leg Spacer". When installing the Rungs into the Leg Notches, install the two outside legs first. Then use the spacer to determine the exact center of the rung and attach the middle leg. Attach the Center Rail to the Center Legs with the 8" carriage bolts and install 2-1/2" screws surrounding the carriage bolt on both sides.

Shown here are both Center Leg Spacers



Shown here is a close-up of one Center Leg Spacer

