

How to Change the Height Yourself

12/13/23

If you decide later on to raise or lower the bed frame or want to use a thinner or thicker mattress you can change the height of the bed frame yourself following these instructions. Using a 3/8" drill bit you can re-drill holes into the legs at any height you need. You can fill the old hole with a 3/8" wood dowel rod and sand it smooth. To get the height you need you can use our Height Calculator at <https://www.collegebedlofts.com/loft-bed-height.html> to determine the amount of space you will get above and underneath the bed slats. See instructions on the diagram below.

After installing the Rails, remember to install (4) 2-1/2" screws around the Carriage Bolt. The Carriage Bolt provides the weight capacity and the four screws gives it stability.

