

Loft with End Shelves Assembly Instructions

2/18/22



This set of instructions is for a loft bed with a custom set of shelves built into the end of the bed. You will first assemble the bed following the standard assembly instructions.

The shelves may be placed either on the right or left. Please note the placement of the 12" wide legs. One leg will have 2x2 shelf supports attached. Make sure you place that leg on the side where you want the shelves placed, see picture below.

Picture of the completed bed.



Now you will install the Center Leg Shelf Support and Shelves at the same time. Coat the inside of the Center Leg notches with glue as you did when assembling the main bed. Place the Center Leg in position as shown in this picture and place the bottom shelf on top of the 2x2 shelf supports. Make sure the center and outside legs are tight against the shelf.

Attach the shelf with 1-5/8" screws. Now attach the remaining shelves from the bottom-up following the same process.

When done with the shelves, attach the rung to the center leg with 2-1/2" screws.

Wait at least 2 hours for the glue to dry before placing any pressure on the bed.