

Plywood Platform Installation Instructions

The plywood platform is attached to the bed slats. First lay out the bed slats spacing them roughly 3" apart. When laying out the plywood on top of the bed slats position the slats so that they are underneath where two pieces of plywood are joined together. All plywood joints going the width of the bed must have a bed slat beneath it. Fasten the bed slats to the rails using 2-1/2" screws. Starting at the footboard end attached the plywood to the bed slats with 1-5/8" screws spacing them 12" apart. Place the screw 3/4" from edge of plywood.

Please Note: If you have the entrance at the foot of the bed and are using the Safety Rail Brace then one sheet of plywood will be 2-1/4" narrower to allow space for the Safety Rail Brace. If this is a bunk bed then the top bunk will use the narrower plywood and the bottom bunk will use the standard width plywood.

Items included: (4) or (6) Pieces of plywood cut as below (1) Bag of 1-5/8" screws

Twin Regular 39 x 75

18-3/4" x 37-3/4"
18-3/4" x 37-3/4"
18-3/4" x 37-3/4"
18-3/4" x 37-3/4"

Twin XL 39 x 80

20" x 37-3/4"
20" x 37-3/4"
20" x 37-3/4"
20" x 37-3/4"

Twin XXL 39 x 84

21" x 37-3/4"
21" x 37-3/4"
21" x 37-3/4"
21" x 37-3/4"

Full Regular 54 x 75

18-3/4" x 48"	4-3/4"
18-3/4" x 48"	x 37-1/2"
18-3/4" x 48"	4-3/4"
18-3/4" x 48"	x 37-1/2"

Full XL 54 x 80

20" x 48"	4-3/4"
20" x 48"	x 40"
20" x 48"	4-3/4"
20" x 48"	x 40"

Full XXL 54 x 84

21" x 48"	4-3/4"
21" x 48"	x 42"
21" x 48"	4-3/4"
21" x 48"	x 42"

Queen XL 60 x 80

20" x 48"	10-3/4"
20" x 48"	x 40"
20" x 48"	10-3/4"
20" x 48"	x 40"

Queen XXL 60 x 84

21" x 48"	10-3/4"
21" x 48"	x 42"
21" x 48"	10-3/4"
21" x 48"	x 42"