

Safety Rail Spacer Block

If you are installing more than three Safety Rails we will provide you with two Safety Rail Spacer Blocks. You may use this block to set the spacing between the safety rails.

