

Short Shelf with Cork/White Board Assembly Instructions

If you purchased the 5-1/2" deep Short Bookshelf and it has a Corkboard or Whiteboard just above it use this set of instructions. The Corkboard or Whiteboard is installed first and rests on top of the Rung. The shelf is moved forward 1-1/2" to allow the full width of the shelf to be used and a Back Shelf Support is used to support the center of the shelf.

Install the Back Shelf Support (3/4" x 3/4" x 12") with (2) 1-5/8" screws into the top front of the rung centered between the legs. Install the (2) Shelf Supports with (2) 2-1/2" screws as shown in the diagram below. Attach the shelf with 1-5/8" screws.

