

Pipe Grab Handle Assembly Instructions

4/7/23

The Pipe Grab Handle is installed at the entrance to the bed. It may be installed anywhere to make it easier for climbing up and down.

Please note there will be some oil residue on the pieces (from the manufacturing process). We recommend you wash the pieces with any type of household cleaner before installation.

Assemble the pieces as shown below, tighten the pieces as tight as possible by hand.



Attach the Pipe Grab Handle near the top of the entrance to one of the legs or safety rail support. The wood you are attaching this to must be 1-1/2" thick. Do not attach it to a safety rail. Use the 1/8" drill bit to pre-drill pilot holes to prevent the wood from splitting.

(1) Pipe Grab Handle

- ___ (1) Pipe Section 5"
- ___ (2) Street Elbows
- ___ (2) Flanges
- ___ (8) 1-1/2" Screws
1.4 oz.

(2) Pipe Grab Handles

- ___ (2) Pipe Section 5"
- ___ (4) Street Elbows
- ___ (4) Flanges
- ___ (16) 1-1/2" Screws
2.6 oz.