Triple Bunk Bed Assembly Instructions



The triple bunk bed is set up exactly the same as the normal bunk bed except is has three levels instead of two. The top bunk headboard can be positioned at either end and you will climb up at the footboard end.

If you ordered the Home Use Safety Rails they are installed on both levels as shown above. At the footboard end there is only one safety rail that is positioned 5" above the top of the middle mattress. This makes it easier to climb up into the top bunk.

The triple bunk bed comes with a short vertical ladder on the front (long) side that is used to climb up into the middle bunk. It may be installed either on the left or right side.

The top and middle bed rails (that support the bed slats) are 2x6's. The bottom bed rails are narrower and rest on the floor. They are attached to the inside of the legs with 2-1/2" screws through the bed rails into the legs.





